



VA U.S. Department
of Veterans Affairs

A.	COORDINATE PROJECT PHASING AND WORK AREA WITH GC120 SERIES DRAWINGS AND SPECIFICATIONS.
B.	DEMOLISH ALL FIXTURES IN PROJECT AREA.
C.	COORDINATE WITH THE COR AND TURN OVER ALL FIXTURES, VALVES, OR OTHER DEVICES THAT THE GOVERNMENT TAGS AS SALVAGE OR DIRECTS THE CONTRACTOR TO SALVAGE.
D.	UTILITY SERVICES MUST BE MAINTAINED TO THE FLOOR ABOVE OR BELOW. ANY DISRUPTION OF SERVICES SHALL BE COORDINATED WITH THE COR 2 WEEKS BEFORE THE DISRUPTION. SERVICES SHALL NOT BE OUT FOR MORE THAN 8 HOURS OR AS ALLOWED BY THE COR.
E.	ALL WORK ON THE FLOORS BELOW SHALL BE DONE ON NIGHTS OR WEEK ENDS UNLESS OTHERWISE PERMITTED BY COR.
F.	SEE PL001 FOR ADDITIONAL GENERAL NOTES.
G.	REMOVE EXISTING ZONE BOX. FILL SUBSEQUENT HOLE WITH LIKE MATERIALS.

1. DEMOLISH EXISTING HEADWALLS, TYPICAL.
2. DISCONNECT EXISTING OXYGEN FROM MAIN, CAP DURING DEMOLITION. RECONNECT DURING INSTALLATION OF NEW MEDICAL GAS PIPING
3. EXISTING MEDICAL GAS PIPING DOWN TO FIRST FLOOR TO REMAIN, EXISTING PIPE CHASE TO REMAIN UNDISTURBED.
4. EXISTING 3/4" OXYGEN UP TO THIRD FLOOR TO REMAIN.
5. PRIOR TO THE START OF DEMOLITION, REMOVE PIPE CAPS AND INSTALL MEDICAL GAS VALVES. COORDINATE WITH VA TO SCHEDULE THE MEDICAL GAS SHUT-DOWN DURING THE VALVE INSTALLATION.
6. CAP EXISTING PIPING FOR PHASE 2.

 2 HOUR FIRE/ SMOKE BARRIER