

SECTION 07 21 00
THERMAL INSULATION

PART 1 GENERAL

1.01 SECTION INCLUDES

- A. Board insulation and integral vapor retarder at cavity wall construction, perimeter foundation wall, and exterior wall behind exterior wall finish.
- B. Batt insulation and vapor retarder in exterior wall and ceiling construction.
- C. Batt insulation for filling perimeter window and door shim spaces and crevices in exterior wall and roof.

1.02 RELATED REQUIREMENTS

- A. Section 07 26 00 - Vapor Retarders: Separate vapor retarder materials.

1.03 REFERENCE STANDARDS

- A. ASTM C165 - Standard Test Method for Measuring Compressive Properties of Thermal Insulations; 2007 (Reapproved 2017).
- B. ASTM C553 - Standard Specification for Mineral Fiber Blanket Thermal Insulation for Commercial and Industrial Applications; 2013 (Reapproved 2019).
- C. ASTM C578 - Standard Specification for Rigid, Cellular Polystyrene Thermal Insulation; 2019.
- D. ASTM C612 - Standard Specification for Mineral Fiber Block and Board Thermal Insulation; 2014 (Reapproved 2019).
- E. ASTM E84 - Standard Test Method for Surface Burning Characteristics of Building Materials; 2021a.
- F. ASTM E136 - Standard Test Method for Assessing Combustibility of Materials Using a Vertical Tube Furnace at 750°C; 2019a.
- G. NFPA 285 - Standard Fire Test Method for Evaluation of Fire Propagation Characteristics of Exterior Non-Load-Bearing Wall Assemblies Containing Combustible Components; 2019.

1.04 SUBMITTALS

- A. See Section 01 30 00 - Administrative Requirements for submittal procedures.
- B. Manufacturer's Certificate: Certify that products meet or exceed specified requirements.
- C. Manufacturer's Installation Instructions: Include information on special environmental conditions required for installation and installation techniques.
- D. Test Reports: Submit evaluation service reports or other independent testing agency reports showing compliance with specified performance characteristics and physical properties.

1.05 QUALITY ASSURANCE

- A. Use only installers with 5 years minimum experience with work similar to work of this Section.

1.06 SEQUENCING

- A. Sequence work to ensure fireproofing and firestop materials are in place before beginning work of this section.
- B. Coordinate work of this Section with roofing, wall or deck work and with work of other trades for proper time and sequence to avoid construction delays.
- C. Pre-installation Meeting: Convene pre-installation meeting after Award of Contract and one week before starting work of this Section to verify project requirements, substrate conditions and coordination with other building sub-trades, and to review manufacturer's written installation instructions.

1.07 FIELD CONDITIONS

- A. Do not install insulation adhesives when temperature or weather conditions are detrimental to successful installation.

PART 2 PRODUCTS

2.01 FOAM BOARD INSULATION MATERIALS

- A. Extruded Polystyrene (XPS) Board Insulation: Comply with ASTM C578 with either natural skin or cut cell surfaces.
 - 1. Type and Compressive Resistance: Type IV, 25 psi (173 kPa), minimum.
 - 2. Flame Spread Index (FSI): Class A - 0 to 25, when tested in accordance with ASTM E84.
 - 3. Smoke Developed Index (SDI): 450 or less, when tested in accordance with ASTM E84.
 - 4. Type and Thermal Resistance, R-value: Type IV, 5.0 (0.88), minimum, per 1 inch thickness at 75 degrees F mean temperature.
 - 5. Complies with fire resistance requirements indicated on drawings as part of an exterior non-load-bearing exterior wall assembly when tested in accordance with NFPA 285.
 - 6. Board Edges: Square.
 - 7. Type and Water Absorption: Type IV, 0.3 percent by volume, maximum, by total immersion.
 - 8. Products:
 - a. DuPont de Nemours, Inc: www.building.dupont.com
 - b. Owens Corning Corporation: www.ocbuildingspec.com.
 - c. Substitutions: See Section 01 60 00 - Product Requirements.

2.02 FIBER BLANKET INSULATION MATERIALS

- A. Flexible Glass Fiber Blanket Thermal Insulation: Preformed insulation, complying with ASTM C665; friction fit.
 - 1. Flame Spread Index: 25 or less, when tested in accordance with ASTM E84.
 - 2. Smoke Developed Index: 450 or less, when tested in accordance with ASTM E84.
 - 3. Combustibility: Non-combustible, when tested in accordance with ASTM E136.
 - 4. Thickness: As indicated on Drawings.
 - 5. Facing: Unfaced.
 - 6. Products:
 - a. CertainTeed Corporation: www.certainteed.com.
 - b. Johns Manville: www.jm.com.
 - c. Owens Corning Corporation: www.ocbuildingspec.com.
 - 7. Substitutions: See Section 01 60 00 - Product Requirements.

2.03 ACCESSORIES

- A. Sheet Vapor Retarder: See Section 07 26 00.
- B. Tape: Polyethylene self-adhering type, mesh reinforced, 2 inch wide.
- C. Insulation Fasteners: Impaling clip of unfinished steel with washer retainer and clips, to be adhered to surface to receive insulation, length to suit insulation thickness and substrate, capable of securely and rigidly fastening insulation in place.

PART 3 EXECUTION

3.01 EXAMINATION

- A. Verify that substrate, adjacent materials, and insulation materials are dry and that substrates are ready to receive insulation.
- B. Verify substrate surfaces are flat, free of honeycomb, fins, irregularities, or materials or substances that may impede adhesive bond.

3.02 BOARD INSTALLATION AT EXTERIOR WALLS

- A. Adhere 6 inches wide strip of polyethylene sheet over expansion joints with double beads of adhesive each side of joint.
 - 1. Tape seal joints between sheets.
 - 2. Extend sheet full height of joint.
- B. Apply adhesive to back of boards:
 - 1. Three continuous beads per board length.
 - 2. Full bed 1/8 inch thick.
- C. Install rigid insulation directly to steel studs or exterior grade sheathing at 16 inches on center with manufacturer recommended mechanical fasteners, and tape joints with manufacturer's minimum 4 inches wide sealant tape; comply with ASTM E2357.
- D. Install boards horizontally on walls.
- E. Cut and fit insulation tightly to protrusions or interruptions to the insulation plane.

3.03 BATT INSTALLATION

- A. Install insulation and vapor retarder in accordance with manufacturer's instructions.
- B. Install in exterior wall and roof spaces without gaps or voids. Do not compress insulation.
- C. Trim insulation neatly to fit spaces. Insulate miscellaneous gaps and voids.
- D. Fit insulation tightly in cavities and tightly to exterior side of mechanical and electrical services within the plane of the insulation.
- E. At metal framing, place vapor retarder on warm side of insulation; lap and seal sheet retarder joints over face of member
- F. Tape seal tears or cuts in vapor retarder.
- G. Extend vapor retarder tightly to full perimeter of adjacent window and door frames and other items interrupting the plane of the membrane; tape seal in place.
- H. Batt Insulation that is not the full depth of the studs needs to be secured in place.
- I. Fill the space between curtain wall frames and the wall opening with batt insulation.

3.04 PROTECTION

- A. Do not permit installed insulation to be damaged prior to its concealment.

END OF SECTION

This page was intentionally left blank for duplex printing.