

QUALITY PROFESSIONAL REQUIREMENTS

The Subcontractor shall designate a qualified Quality Professional appointed to the project for the duration of their work. This person shall have authority to act for and on behalf of the Subcontractor in all matters related to the quality of the Subcontractor's work. Full Time Subcontractor quality professional(s) shall be personnel other than those performing the work. The Subcontractor shall designate an onsite Quality Professional who shall collaboratively identify quality risk items, with a focus on high-risk items, along with appropriate countermeasures and activities to lower the inherent risk proactively, and measure performance throughout the project delivery cycle for the work being performed on their behalf.

The Subcontractor's Quality Professional shall possess the necessary qualifications to fulfill the Contractor's Quality Management Plan requirements. Subcontractor Quality Professionals shall support the Contractor's Quality Management Plan and maintain the project-specific Quality Management Plan as it pertains to their employees. The intent is to provide a heightened level of quality onsite where quality professionals collaborate together so there is consistency amongst all Quality Professionals. This person shall have an understanding of acceptance criteria, activities to mitigate risk, and regularly update risk items throughout the project to current and near-term risks. The Subcontractor Quality Professional(s) qualifications shall be submitted to the Contractor for review.

Subcontractor Quality Professionals are required to coordinate with the Contractor's Quality Management Team on a daily basis, as well as attend and participate in the weekly QA/QC project site meetings. Subcontractor Quality Professionals shall provide weekly updates/reports of items described above at the weekly QA/QC project site meetings.

- **Required Part Time onsite Quality Professionals** (Part Time Quality Professionals are only permitted when 10 or less personnel are onsite. Part time QPs **can** be a working foreman or superintendent.):
 - Subcontractor Personnel Range 1-10, (1 Part Time Quality Professional)

- **Required Full Time onsite Quality Professionals** (All ranges with more than 10 personnel will require the specified number of full-time quality personnel as shown below. Full time QPs **cannot** be a working foreman or superintendent.):
 - Subcontractor Personnel Range 11-25, 1 Quality Professional
 - Subcontractor Personnel Range 26-50, 2 Quality Professionals
 - For every additional 25 Personnel, 1 additional Quality Professional shall be required