LEGEND

DUCTWORK SYMBOLS

- XX/XX — DUCT WITH ACOUSTICAL LINING
- MANUAL VOLUME DAMPER (SEE BELOW FOR OTHER TYPES)

DAMPER TYPE:
FD - FIRE DAMPER
SD - SMOKE DAMPER
FSD - COMBINATION FIRE/SMOKE DAMPER
BD - GRAVITY BACKDRAFT DAMPER
M - CONTROL DAMPER
*NO MARK INDICATES MANUAL VOLUME DAMPER

- VERTICAL DAMPER IN DUCT (OR OPENING) AT FIRE-RATED PARTITION
- HORIZONTAL FIRE DAMPER AT FLOOR PENETRATION
- CONNECT NEW DUCT TO EXISTING
- MITERED ELBOW (PROVIDE VANES IN ALL SQUARE OR RECTANGULAR ELBOWS, UNLESS NOTED OTHERWISE)
- FAN POWERED TERMINAL UNIT
- TYPICAL SUPPLY AIR TEE WITH SPLITTER DAMPER
- STANDARD ROUND BRANCH DUCT (SPIN-IN)
- STANDARD ROUND BRANCH DUCT (CONICAL)
- STANDARD RECTANGULAR BRANCH DUCT (45° TAKE-OFF)
- STANDARD CONCENTRIC DUCT TRANSITION
- STANDARD ECCENTRIC DUCT TRANSITION
- RECTANGULAR-TO-ROUND DUCT TRANSITION
- SECTION THROUGH ROUND DUCT, SUPPLY OR EXHAUST AS NOTED
- SECTION THROUGH RECTANGULAR SUPPLY DUCT
- SECTION THROUGH RECTANGULAR RETURN DUCT
- SECTION THROUGH RECTAN-GULAR EXHAUST DUCT
- A.D. — ACCESS DOOR IN CEILING
- A.D. — DUCT ACCESS DOOR
- CEILING SUPPLY AIR DIFFUSER, ARROWS INDICATE PATTERN. NO PATTERN SHOWN EQUALS 4-WAY
- CEILING RETURN AIR GRILLE OR RETURN REGISTER
- CEILING EXHAUST AIR GRILLE OR EXHAUST REGISTER
- SIDEWALL SUPPLY OR RETURN REGISTER OR GRILLE
- SUPPLY OR OUTSIDE AIR DUCT UP
- SUPPLY OR OUTSIDE AIR DUCT DOWN
- RETURN AIR DUCT UP
- RETURN AIR DUCT DOWN
- RELIEF OR EXHAUST AIR DUCT UP
- RELIEF OR EXHAUST AIR DUCT DOWN
- IN-LINE 90 DEGREE DROP (RISE) IN DUCT
- UP — INCLINE RISE IN DUCT
- DOWN — INCLINE DROP IN DUCT
- VAV TERMINAL UNIT
- FLEXIBLE DUCT, SIZE AS SHOWN

PIPING SYMBOLS

- PITCH DOWN IN DIRECTION OF ARROW
- DIRECTION OF FLOW
- PIPE ANCHOR
- PIPE GUIDE
- CONCENTRIC REDUCER
- ECCENTRIC REDUCER
- STRAINER WITH BLOWDOWN VALVE
- BRANCH - SIDE CONNECTION
- BRANCH - TOP CONNECTION
- BRANCH - BOTTOM CONNECTION
- RISE OR DROP IN PIPE
- RISER DOWN (ELBOW)
- RISER UP (ELBOW)
- CAPPED PIPE
- BLIND FLANGE
- UNION (SCREWED)
- PUMP
- FLANGED CONNECTION
- TEMPERATURE & PRESSURE PORT
- FLEX PIPE
- FLEX CONNECTION
- BELLOWS CONNECTION (DOUBLE SPHERE NEOPRENE TYPE)
- THERMOMETER
- PRESSURE GAGE WITH COCK
- PS — PRESSURE SWITCH
- FS — FLOW SWITCH
- MANUAL AIR VENT
- AUTOMATIC AIR VENT
- WELDED CONNECTION
- FLANGED CONNECTION
- SOLDERED CONNECTION
- THREADED OR "PRESS" CONNECTION
- BELL & SPIGOT CONNECTION
- SOLVENT CONNECTION

EQUIPMENT SYMBOLS

- NEW EQUIPMENT
- EQUIPMENT CLEARANCE

MISCELLANEOUS

- 001 — KEYNOTE
- POINT OF CONNECTION - NEW TO EXISTING
- FTR - A - B
  A = SCHEDULE TYPE
  B = FEET OF ACTIVE LENGTH

CONTROLS SYMBOLS

- T — ROOM THERMOSTAT
- H — ROOM HUMIDISTAT
- T — TEMPERATURE SENSOR/TRANSMITTER
- H — HUMIDITY SENSOR/TRANSMITTER
- S — DUCT SMOKE DETECTOR
- R — RELAY
- ST — SLAB SENSOR
- VIBRATION SWITCH
- HT — DUCT HUMIDITY SENSOR/TRANSMITTER
- PT — PRESSURE TRANSMITTER
- MOTOR STARTER (LOCAL OR MCC)
- SP — STATIC PRESSURE SENSOR/TRANSMITTER
- DT — DIFFERENTIAL PRESSURE SENSOR/TRANSMITTER
- DP — DIFFERENTIAL PRESSURE SWITCH (DIGITAL)
- T — DUCT AVERAGING TEMPERATURE ELEMENT
- F — FLOW SENSOR
- FR — FREEZESTAT
- FS — FLOW SWITCH
- M — ELECTRIC MOTOR

NORMAL OPEN	NORMAL CLOSED	
		GATE VALVE
		VALVE W/ REDUCERS (GATE VALVE SHOWN)
		GLOBE VALVE
		BUTTERFLY VALVE
		NEEDLE VALVE/ INSTRUMENT VALVE
		3-WAY VALVE
		BALL VALVE
		PLUG VALVE
		ANGLE VALVE

- RS — REFRIGERANT SENSOR
- LIQUID FLOW METER
- RECEIVER PRESSURE GAUGE (PANEL MTD.)
- CT — CURRENT SENSING RELAY
- DA — ELECTRIC DAMPER ACTUATOR
- F — FIRESTAT
- HS — MANUALLY ACTIVATED SWITCH (PULL STAT., PUSH STAT., ETC)
- AQ — AQUASTAT
- LWCO — LOW WATER CUTOFF

CONTROL VALVE SYMBOLS:

- M — ELECTRIC ACTUATOR
- S — SOLENOID ACTUATOR

CONTROL DEFINITIONS:

NORMAL POSITION: INDICATES DEVICE POSITION WHEN THE SYSTEM IS DISABLED OR NOT ENERGIZED

FAIL POSITION: INDICATES DEVICE POSITION WHEN THE CONTROL SIGNAL IS LOST OR UPON A LOSS OF POWER.

NO - NORMALLY OPEN
NC - NORMALLY CLOSED
FO - FAIL OPEN
FC - FAIL CLOSED

VALVE SYMBOLS

- GATE VALVE
- GLOBE VALVE
- CHECK VALVE (NON SLAM)
- PLUG VALVE
- PRESSURE REDUCING VALVE (PRV)
- BUTTERFLY VALVE
- BALL VALVE
- NEEDLE VALVE
- VENTURI FLOW METER
- VALVE IN DROP
- VALVE IN CENTER DROP
- VALVE IN RISE
- S — SOLENOID VALVE
- GATE VALVE W/ 3/4" HOSE THREAD ADAPTER
- TWO-WAY CONTROL VALVE
- THREE-WAY CONTROL VALVE
- SAFETY VALVE OR PRESSURE RELIEF VALVE
- MANUAL BALANCING VALVE
- AUTOMATIC BALANCING VALVE
- TEMPERATURE WELL
- FLANGED VALVE (GATE VALVE SHOWN)
- P — PRESSURE INDEP. CONTROL VALVE (PICV)

EQUIPMENT TAG SYMBOLS

AIR DEVICE TAG

AD - X | 380 — TAG; MAXIMUM AIRFLOW (CFM)

24x12	INDICATES A 24"x12" RECTANGULAR DUCT (NET FREE AREA)
24/12	INDICATES A 24"x12" FLAT OVAL DUCT (NET FREE AREA)
20"ø	INDICATES A 20" ROUND DUCT (NET FREE AREA)

NO.	DATE	REVISION	CHK	APVD
0	09/18/2024	100% ISSUED FOR CONSTRUCTION - EXPANSION	JWG	SJS

DSGN JWG DR RPA JWG APVD SJG

© Jacobs Solutions 2023. ALL RIGHTS RESERVED.
THIS DOCUMENT AND THE IDEAS AND DESIGNS INCORPORATED HEREIN, AS AN INSTRUMENT OF PROFESSIONAL SERVICE, IS THE PROPERTY OF JACOBS AND IS NOT TO BE USED, IN WHOLE OR IN PART, FOR ANY PURPOSE WITHOUT THE WRITTEN AUTHORIZATION OF JACOBS.
REUSE OF DOCUMENTS

Jacobs
1999 Bryan Street Suite 3500 Dallas, TX 75201
214.638.0145 Fax: 214.638.0447
Entity: Jacobs Engineering Group Inc.
License Type: Engineering
License No.: F-2170
Exp. Date: 1/31/2024

STATE OF ARKANSAS
STEVE J. GOODELL
ENGINEER
No. 9593
REGISTERED PROFESSIONAL
09/18/2024
SEAL

Compressor-Building
Camden OSD
Calhoun County, Arkansas
Aerojet Rocketdyne

Jacobs NABHOLZ

MECHANICAL SYMBOLS

SHEET NO
M-002

SCALE	NTS
DATE	09/18/2024
PROJ	D3754502
DWG	CMDN-OSD_Compressor-Building_M-002

PLOT DATE/TIME: 9/17/2024 8:46:33 PM

M-002
9/17/2024 8:46:33 PM
Autodesk Docs://US_D3754500_FED_Aerojet Rocketdyne/D3754540_CMDN_OSD_Compressor-Building_MECH.rvt