


ELEMENTS IN DASHED LINE: NOT IN SCOPE AND FOR REFERENCE ONLY CONNECT MANUAL BUTTERFLY VALVE INTO STEEL BASE WHEN NOT IN USE ---**UPPER STAND** PRESSURE GAUGE (TYP) — MANUAL ISOLATION BALL VALVE (TYP) — 2" PHWR TO PHWR MAIN ► FLEXIBLE HOSE (TYP)

UPPER STAND PHW HOSE CONNECTION DETAIL
SCALE NTS



1. SUPPORT RIGID PIPING WITH FLOOR MOUNTED STEEL BASE

FLOOR LEVEL PHW HOSE CONNECTION DETAIL
SCALE NTS

Autodesk Docs://US_D3754500_FED_Aerojet Rocketdyne/D37545N0_CMDN_OSD_GMLRS_MECH.rvt

PLOT DATE/TIME: 9/18/2024 2:37:33 PM

D3754502

CMDN-OSD_GMLRS_MH