

Quality People. Building Solutions.

Comfort Systems USA (Arkansas), Inc. P.O. Box 16620 Little Rock, AR 72231 Phone 501-834-3320 Fax 501-834-5416

Date: 12/1/2022 Return Request: 12/11/2022 Project: New Dormitories – Bldg. 6 Supplier: Little Rock Winnelson Manufacturer: Various Submittal: Healthcare Plumbing Fixtures Submittal Number: 22 43 00-01 Drawing # and Installation: Plumbing Fixtures

ARCHITECT

Stocks Mann Architects 401 W. Capitol, Suite 402 Little Rock, AR 72201 501-370-9207

GENERAL CONTRACTOR

Alessi Keyes Construction 10623 Maumelle Blvd. N. Little Rock, AR 72113 501-225-6699

Notes:

<u>ENGINEER</u>

Bernhard TME 1 Allied Drive #2600, Building 2 Little Rock, AR 72202 501-666-6776


MECHANICAL SUBCONTRACTOR

Comfort Systems USA (Arkansas), Inc. 9924 Landers Rd. N. Little Rock, AR 72117 501-834-3320

CSUSA PROJECT NO. 22-102 jon@comfortar.com

ALESSI KEYES CONSTRUCTION REVIEWED FOR GENERAL COMPLIANCE WITH CONTRACT DOCUMENTS Charley Dawson 1/19/2023

CS-1 CLINICAL SINK





T&S BRASS AND BRONZE WORKS, INC. 2 Saddleback Cove / P.O. Box 1088 Travelers Rest, SC 29690

Model No.

B-0664-03

Item No.

Travelers Rest. SC: 800-476-4103 • Simi Valley, CA: 800-423-0150 • Fax: 864-834-3518 • www.tsbrass.com


ravelers Rest, SC: 800-476-4103 • Simi Valley, CA: 800	-423-015() • Fax: 864-834-3	3518 • www.tsbrass.com
	ITEM NO.	SALES NO.	DESCRIPTION
	1		Spout Assembly, Polish Chrome w/ Lower Clevis
-	2	B-0969	1/2" NPT Vacuum Breaker
1	3	002534-25	Close Nipple, 1/2" NPT
-	4		Split Ring Pipe Clamp Lower Assembly
	5	016863-20	Clamp Split Bushing (Set of 2 halves)
r	6		Wrist Action Handle, Red Index & Screw
-			Quarter Turn Eterna Cartridge W/ Spring
	7	012443-40NS	Check, RTC
	8	001193-19NS	Red Button Index, Press-in
	9		Wrist Action Handle - New Style
	10	018506-19NS	Blue Button Index, Press-in
1 3	11	000925-45	Lab Handle Screw
	12	B-WH4C-NS	
			Overter Turn Eterna Cortridgo W/ Spring
	13	012442-40NS	Check, LTC
	14	001019-45	Coupling Nut Washer
	15	000721-25	Flange Coupling Nut
	16	000611-25	Extension, 1 3/4" Long
	17	000610-25	Extension, 2 3/4" Long
	18	000763-20	Seat
	19	002892-40	Service Stop w/ Cap
	20	001605-45	Сар
	21	001802-45	Handle, Supply Stop "T"
	22	002432-45	Screw, Tee Handle
	(13		
Product Specifications: 8" Wall Mount Service Sink Faucet, Quarter-Turn Spring Checks, Split-Ring Lower Support Clamp Tubes, 4" Wrist Handles, Polished Chrome Finish Female Inlets, Intergral Service Stops & Garden	for use o i, Vacuui	n Ø 1 1/2" Flusi n Breaker, 1/2"	h NPT NPT NPT NPT NPT NPT NPT NPT NPT NPT
Drawn: KJG Checked: JRM Approve	d: JHB	Date: 01	1/11/23 Scale: NTS Sheet: 2 of



Aquaflush[®] Z6000 Series Aquaflush Exposed Flushometer

Installation, Operation, Maintenance and Parts Manual

Patented and Patents Pending



NOTICE: READ ENTIRE MANUAL PRIOR TO INSTALLING PRODUCT.

M WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov

ADVERTENCIA: Cáncer y daño reproductivo - www.P65Warnings.ca.gov

A AVERTISSEMENT: Cancer et effets néfastes sur la reproduction - www.P65Warnings.ca.gov

LIMITED WARRANTY

LIWITED WARKANT T All goods sold hereunder are warranted to be free from defects in material and factory workmanship for a period of three years from the date of purchase. Decorative finishes warranted for one year. We will replace at no costs goods that prove defective provided we are notified in writing of such defect and the goods are returned to us prepaid at Sanford, NC, with evidence that they have been properly maintained and used in accordance with instructions. We shall not be responsible for any labor charges or any loss, injury or damages whatsoever, including incidental or consequential damages. The sole and exclusive remedy shall be limited to the replacement of the defective goods. Before installation and use, the purchaser shall determine the suitability of the product for his intended use and the purchaser assume all risk and liability whatever in connection therewith. Where permitted by law, the implied warranty of merchantability is expressly excluded. If the products sold bereunder are "consumer products" the implied warranty of merchantability is limited to a is expressly excluded. If the products sold hereunder are "consumer products," the implied warranty of merchantability is limited to a period of three years and shall be limited solely to the replacement of the defective goods. All weights stated in our catalogs and listed are approximate and are not guaranteed.

NOTE: The information in this manual is subject to change at any time without notice. Installations may be performed at different times of construction by different individuals. For this reason, these instructions should be left on-site with the facility or maintenance manager.

Zurn Industries, LLC 511 W. Freshwater Way, Milwaukee, WI U.S.A. 53204 · Ph. 1-855-ONE-ZURN, Fax 919-775-3541 In Canada | Zurn Industries Limited 7900 Goreway Drive Unit 10, Brampton, Ontario L6T5W6 · Ph. 905-405-8272, Fax 905-405-1292

WINDAR ZHEN CON

Aquaflush® Rough-In, Product Specification, Models and Options

ENGINEERING SPECIFICATION: ZURN Aquaflush Exposed Closet Flush Valve – Exposed, quiet diaphragm-type, chromeplated flushometer valve with a polished exterior. Complete with a chloramine resistant, dual seal diaphragm with a clog resistant by-pass. The valve is ADA compliant with a non-hold open and no leak handle feature, high back pressure vacuum breaker, one-piece hex cou pling nut, adjustable tailpiece, spud coupling, and flange for top spud connection. Control stop has internal siphon-guard protection. Internal seals are made of chloramine resistant materials.

Z6000PL Aquaflush Plus is furnished as specified above and includes sweat solder kit, vandal-resistant stop cap, and cast wall flange with setscrew.

MODELS

Z6000 - 1-1/2" Water Closet Valve with top spud connection. Z6010 - 1-1/2" Water Closet Valve with back spud connection.

Z6001 – 1-1/4" Urinal Valve with top spud connection.


Z6003 – 3/4" Urinal Valve with top spud connection.


FLOWS


-FF	Full Flow
	3.0 Gal. for Urinal, 4.5 Gal. for Water Closet
-HET	High Efficiency Toilet (PL Only)
	1.28 Gal. for Water Closet
-WS1	Low Consumption
	1.0 Gal. for Urinal, 1.6 Gal. for Water Closet
-WS	1.5 Gal. for Urinal, 3.5 Gal. for Water Closet
-ULF	0.125 Gal. for Urinal (PL Only)


OPTIONS


- ____-BG BioCare Handle
- ____-H Handle on Front of Flush Valve
- L 1" [25] Metal Push Button
- _____-L3 3" [76] Metal Push Button
- -VC Vandal-Resistant Stop Cover
- -YB Sweat Solder Kit
- -YC Cast Wall Flange
- -YJ Split Ring Pipe Support
- -YK Solid Ring Pipe Support
- ____-YO Bumper on Stop Angle











Models: Z6001 (1-1/4" urinal flush valve) Z6003 (3/4" urinal flush valve) -WS1 (Water Saver) 1.0 Gal. Low Consumption -ULF (Ultra Low Flow) 0.125 Gal.

Sweat Solder Adaptor Installation Instructions

Important:

- All plumbing is to be installed according to state and local codes and regulations.
- Water supply lines need to allow proper water flow for each fixture.
- · Flush all lines of any debris before making connections.
- Do not use pipe sealant or plumbing grease on any fitting other then the control stop inlet.


The Aquaflush valve is designed to operate under various water pressures with a recommended range between 10 and 100 psi (69 to 689 kPa). Each Zurn valve is tested for proper performance at the factory before being shipped. Consult the product pages of the catalog for available flow options.

Most low consumption fixtures (1.28 and 1.6 gallon) require a minimum of 25 psi running pressure through the valve to obtain proper evacuation. Please be sure to consult fixture manufacturer on minimum running water supply requirements for proper evacuation.

When installing your quality Zurn valve it is rec om mend ed that to protect the polished finish you do not use a toothed wrench. This will cause gouges and scratches on your valve.


STEP NO. 1

Measure distance from finished wall to center line of fixture spud; cut water supply pipe 1-1/4" shorter than this mea sure ment. Chamfer O.D. and I.D.




STEP NO. 2

Slide threaded adapter onto supply pipe until shoulder stops on end of pipe. Then sweat-solder the adapter to water supply pipe.




STEP NO. 3

Measure from finished wall to first thread of adapter for length of chrome tube. Cut chrome tube this length 'x'.




STEP NO. 4


Slide wall escutcheon over chrome tube and slide both chrome tube and wall escutcheon over supply pipe pushing the wall escutcheon all the way to the wall.




STEP NO. 5 Screw control stop onto water supply water adaptor.




 Install stop valve assembly using proper size supply escutcheon and sweat solder adapter kit if applicable (see 1). Thread sealing compounds should be used on male NPT threads only.




2. Prior to inserting the flush valve tailpiece into stop valve, be certain that the O-ring seal is located in O-ring seal groove at the end of the tailpiece and the locking nut and locking snap ring are located as shown below (see 2). Care should be taken not to damage the O-ring when inserting the tailpiece into the stop valve. If lubrication is needed, wetting the O-ring with water will be sufficient.




3. Insert the flush valve tailpiece into the stop valve and hand tighten the lock nut to the stop valve. Plumb the entire unit (see 3).



4. Determine the length of vacuum breaker tube required to join the flush valve and fixture spud. Cut the vacuum breaker tube, if re quired, to this length (see 4a). Assemble the vacuum breaker tube assembly and spud nut assembly to the flush valve and fixture spud (see 4b).




5. Hand tighten spud nut and vacuum breaker tube nut to fixture and flush valve. Adjust the valve assembly for plumb. Tighten fixture spud nut, vacuum breaker tube nut and lock nut with a wrench.




Aquaflush[®] Installation Instructions

6. When all flush valves are connected to the fixtures and water pressure is available, it is recommended that the supply piping be flushed to remove dirt, pipe chips, etc. from system. Before the water is turned on, be sure all stop valves to the flush valves are closed off tight. The stop valves can be opened and closed by using the adjusting screw located at the center of the stop valve cap, behind the stop snap cap screw cover if already installed (see 6a). Stop valve adjustments can only be made by using the adjusting screw. It is not neces sary to remove the stop valve cap when making adjustments. If for any reason it becomes necessary to remove the stop valve cap, be certain the water is shut off at the main supply valve.




Use the following procedure to flush out the supply piping:

- A. Remove the main valve body cover.
- B. Remove the working parts from the flush valve (shown in 6b).
- C. Replace the main valve body cover and plastic cover without reinstalling the working parts.
- D. Open the stop valve by using the stop adjusting screw, and flush out all debris from pipe and connections.
- E. Shut stop, open cover, replace the working parts, replace plastic cover and main valve body cover and tighten.



This procedure should also be followed when the system has been drained for some time, as occurs in athletic fields, recreation parks, etc.

7. The Aquaflush flush valves are preset for fixture volume as marked on the valve cartons. The valve does not require regulation for vari a tion in water pressure within its operating range. To set the flush valve for proper operation, gradually adjust the stop valve open, using the adjusting screw, while actuating the valve until the rate of water flow into the fixture is not excessive, yet is sufficient enough to adequately evacuate the waste. The final setting for urinals should be such that the fixture will not overflow when the valve is actuated in succession. The stop snap cap screw cov er should be secured after final adjustments have been made.





Aquaflush[™] Exposed Repair Kits

Part Identification 1. Handle Nut

- 2. Handle
- 3. Actuator Rod
- 4. Handle O-Ring
- 5. Handle Spring
- 6. Handle Seal Retainer
- 7. Handle Seal
- 8. Handle Gasket
- 9. Valve Body Cover
- 10. Plastic Wrap
- 11. Trip Mechanism
- 12. Diaphragm Assembly
- 13. Valve Body
- 14. Vacuum Breaker Insert
- 15. Vacuum Breaker Duckbill
- 16. Vacuum Breaker Tube
- 17. Vacuum Breaker Tube Nut
- 18. Spud Nut
- 19. Spud Friction Washer
- 20. Spud Sleeve
- 21. Spud Escutcheon
- 22. Tailpiece 23. Snap Ring
- 24. Tailpiece O-Ring
- 25. Locking Nut
- 26. Wall Flange
- 27. Stop Body
- 28. Piston Seal
- 29. Piston Seal
- 30. Stop Spring
- 31. Guide O-Ring
- 32, Piston Guide
- 33. Guide Holder
- 34. Adjusting Screw
- 35, Stop Cap
- 36. Snap Cap Screw Cover


Covers and Repair Kits	Product No.			
Outside Cover - CP - Item 9	P6000-LL-CP			
Inside Cover – Item 10	P6000-L			
HET Water Closet Kit – 1.28 gal. flush (PL Only)	P6000-ECA-HET			
ULF Urinal Kit – 0.125 gal. flush (PL Only)	P6000-EUA-ULF			
Low Consumption Closet Kit – 1.6 gal. flush	P6000-ECR-WS1			
Water Saving Closet Kit - 3.5 gal. flush	P6000-ECR-WS			
Full Flow Closet Kit – 4.5 gal. flush	P6000-ECR-FF			
Low Consumption Urinal Kit 1.0 gal. flush	P6000-EUR-WS1			
Water Saving Urinal Kit – 1.5 gal. flush	P6000-EUR-WS			
Full Flow Urinal Kit – 3.0 gal. flush	P6000-EUR-FF			
Repair Parts - Inside Parts	Product No.			
Urinal Relief Valve - Item 11	P6000-EU13			
	P6000-EC13			
I Closet Relief Valve - Item 11	P6000-EC13			
Closet Relief Valve - Item 11				
Aquaflush Rebuild Kits	Product No.			
Aquaflush Rebuild Kits				
Aquaflush Rebuild Kits Closet and Urinal Rebuild Kits Include	Product No.			
Aquaflush Rebuild Kits	Product No. P6000-EC-WS-RK			
Aquaflush Rebuild Kits Closet and Urinal Rebuild Kits Include	Product No. P6000-EC-WS-RK P6000-EC-WS1-RK P6000-EU-WS-RK			
Aquaflush Rebuild Kits Closet and Urinal Rebuild Kits Include	Product No. P6000-EC-WS-RK P6000-EC-WS1-RK			
Aquaflush Rebuild Kits Closet and Urinal Rebuild Kits Include Items 3-8, 11, 12, 24, 28-34	Product No. P6000-EC-WS-RK P6000-EC-WS1-RK P6000-EU-WS-RK P6000-EU-WS1-RK			
Aquaflush Rebuild Kits Closet and Urinal Rebuild Kits Include Items 3-8, 11, 12, 24, 28-34 Handle Assembly and Repair Kits	Product No. P6000-EC-WS-RK P6000-EC-WS1-RK P6000-EU-WS-RK P6000-EU-WS1-RK Product No.			
Aquaflush Rebuild Kits Closet and Urinal Rebuild Kits Include Items 3-8, 11, 12, 24, 28-34 Handle Assembly and Repair Kits ADA Handle Assembly (Side) Includes Items 1-8	Product No. P6000-EC-WS-RK P6000-EC-WS1-RK P6000-EU-WS-RK P6000-EU-WS1-RK P6000-EU-WS1-RK P6000-EU-WS1-RK Product No. P6000-M-ADA			
Aquaflush Rebuild Kits Closet and Urinal Rebuild Kits Include Items 3-8, 11, 12, 24, 28-34 Handle Assembly and Repair Kits ADA Handle Assembly (Side) Includes Items 1-8 Handle Repair Kit (Side) Includes Items 4-8	Product No. P6000-EC-WS-RK P6000-EC-WS1-RK P6000-EU-WS-RK P6000-EU-WS1-RK Product No. P6000-M-ADA P6000-MK			
Aquaflush Rebuild Kits Closet and Urinal Rebuild Kits Include Items 3-8, 11, 12, 24, 28-34 Handle Assembly and Repair Kits ADA Handle Assembly (Side) Includes Items 1-8 Handle Repair Kit (Side) Includes Items 4-8 Handle Seal Includes Item 8	Product No. P6000-EC-WS-RK P6000-EC-WS1-RK P6000-EU-WS-RK P6000-EU-WS1-RK Product No. P6000-M-ADA P6000-MK P6000-M9			
Aquaflush Rebuild Kits Closet and Urinal Rebuild Kits Include Items 3-8, 11, 12, 24, 28-34 Handle Assembly and Repair Kits ADA Handle Assembly (Side) Includes Items 1-8 Handle Repair Kit (Side) Includes Items 4-8	Product No. P6000-EC-WS-RK P6000-EC-WS1-RK P6000-EU-WS-RK P6000-EU-WS1-RK Product No. P6000-M-ADA P6000-MK			

P6000-MH

Control Stop Repair Kit and Parts	Product No.
Control Stop Repair Kit for 1" and 34"	P6000-D-SD
Includes Items 28-34	
Seal Seat for 1" and 34", Includes Item 24	P6000-D42
VP Control Stop Repair Kit for 1" and 3/4"	P6000-D-VP
Sweat Solder Connection with Cast Wall Flange	P6000-YB
Sweat Solder Solitiesteri with Sast Hain Lange	
Adjustable Tailpieces	Product No.
Adjustable Tailpiece for Standard Flush Valve	P6000-J1
Includes Items 22-25	
Tailpiece Coupling Assembly Includes Items 23-25	P6000-K
Tailpiece Locking Ring Includes Item 23	P6000-C30
Tailpiece O-Ring Includes Item 24	P6000-C31
Coupling Nut Includes Item 25	P6000-C32
Flush Connections and Spud Coupling Kits	Product No.
Flush Tube Assembly for Flush Valves Includes	P6000-A
Items 14-17, Specify diameter and length.	
Vacuum Breaker Repair Kit Includes Items 14-15	P6000-B-HP
Spud Coupling Assembly Includes Items 18-21.	P6000-H-CP
Specify size.	

Handle Assembly (Front) Includes Items 2-9

Includes Items 4-9



Aquaflush® Trouble Shooting Guide

Problem	Cause*	Corrective Action*			
Valve will not operate.	 Stop valve is closed. Supply valve is closed. 	1.) Open stop valve. 2.) Open supply valve.			
Insufficient volume of wa- ter to adequately siphon fixture.	 "1.) Stop valve is not open enough. 2.) Urinal trip mechanism installed in wrong kit, urinal for closet. 3.) Insufficient volume or pressure at supply. 	 Open stop valve for desired volume of water. Replace urinal part with proper closet valve part. If gauges are not available to measure supply pressure or volume of water at the valve, completely remove the working parts and open the stop valve to allow water to pass through the empty valve. If the supply is adequate to siphon the fixture, the guide ring (#16) may be removed from the guide assembly to provide additional flow (see page 5). Should this prove unsatisfactory, steps should be taken to increase the pressure and/or supply. 			
Flush valve shuts off too quickly.	 Damaged or punctured diaphragm. Enlarged by-pass orifice. " 	 Install new P6000-EUR or P6000-ECR replacement kit to remedy the problem. (#12 thru #17) Install new P6000-EUR or P6000-ECR replacement kit to remedy the problem. (#12 thru #17) " 			
Valve is short flushing.	 Diaphragm kit is not matched to the fixture. Urinal trip mechanism (black #12) is in the closet flush valve. 	"1.) Install the proper P6000-EUR or P6000-ECR replacement kit to remedy the problem. (#12 thru #17) 2.) Install closet trip mechanism (white #12).			
Valve is flushing too long or not shutting off.	 Trip mechanism not seating properly due to foreign material between trip mechanism and retainer disc. By-pass orifice is plugged or partially plugged. Line pressure is not adequate to force trip mechanism to seal. Cracked cover. (#11) 	 Disassemble parts and rinse thoroughly. Examine by-pass orifice and clean if necessary being certain not to enlarge orifice opening. Pressure is inadequate or has dropped below minimum operating range. Steps should be taken to increase the line pressure. Replace cover with new one. 			
Water splashes out of fixture.	 Supply volume is more than is necessary. Lime accumulation on vortex or spreader holes of fixture. 	 Adjust downward on control stop. Remove the lime build up. 			
Flush is not considered quiet.	 1.) Control stop may not be adjusted for quiet operation. 2.) Fixture may be contributing to noise. 3.) Piping system may be source of noise. 	 Adjust the control stop for quiet operation keeping in mind the fixture evacuation requirements. Check noise created by fixture by placing a cover over the bowl opening to separate valve noise from bowl noise. If it is deter-mined the fixture is too noisy consult with fixture manufacturer. High pressure in the system can sometimes be controlled by the stop valve. Other sources of noise may be the absence of air chambers and shock arrestors, loose pipes, improper size pipes, etc. In these cases the building engineer should be consulted. 			
Handle assembly leaking.	1.) Handle assembly is not tight.	1.) Tighten handle assembly.			

Care of Chrome Plated Surfaces

The suggested cleaning of chrome plated surfaces is simply to clean them with mild soap and water, then dry. Commercial cleaning compounds are never recommended.

Seasonal Use

Valves used in installations subject to shut down because of cold and freezing conditions should be maintained in the following manner. After the main supply has been shut off and the water drained from the system, remove the stop valve cap and stop valve internals to allow the water to drain from the flush valve itself.

*See previous page for numerical references.



ZURN INDUSTRIES, LLC COMMERCIAL BRASS OPERATION, 5900 ELWIN BUCHANAN DRIVE, SANFORD, NC, U.S.A. 27330 PHONE: 1-800-997-3876 FAX: 919/775-3541 www.zurn.com ZURN INDUSTRIES LIMITED 3544 NASHUA DRIVE, MISSISSAUGA, ONTARIO L4V 1L2 PHONE: 905/405-8272 FAX: 905/405-1292

.



Transmittal

PROJECT:	New Dormitories - Phase Booneville Human Develo		SMA PROJECT NO: 2002B			
	Booneville, Arkansas		DATE	:	January 24, 2023	
TO:	Alessi Keyes Construction 10623 Maumelle Blvd. North Little Rock, AR 727		inform	osures are not a us immediately cked below, plea		
ATTN:	Charley Dawson			Acknowledge re Return enclosu	eceipt of enclosures. res to us.	
WE TRANSMIT	:					
VIA:	Herewith	Under separate cover				
	Courier	Mail		E-mail		
	Overnight delivery	Fax	X	Other		
FOR YOUR:						
	Approval/Action	Information		Use as requeste	ed	
	Review & comment	X Use		Other		
THE FOLLOWI		_				
	Drawings	Specifications	X	Digital Files - PI	DF	
X	Submittals	Proposal Request		Digital Files - Of	ther	
	Change Order	Samples		Other		

COPIES	DATE	REV. NO.	DESCRIPTION		ACTION CODE	
1	1/24/2023		Healthcare Plumbing Fixture		А	
ACTION CODE	A. No action required B. Action indicated on item transmitted		C. For signature and return to this office D. For signature and forwarding as noted below under REMARKS	E. See REMA	ARKS below	

COPIES TO: (with enclosures) X Rex Morris, Morris AE By: Trey Tassin 401 W. CAPITOL, SUITE 402

REMARKS



Submittal Comment Sheet

To:	Randy Stocks, Stocks-Mann Architects
From:	Rob Adams, BTME
Date:	January 23, 2023
Project:	Booneville HDC Building #6
Project #	01-20-0003
Ref:	22 43 00 Healthcare Plumbing Fixtures Submittal
Submitted By:	Alessi Keyes Construction



Below find our response for the submittal received on Wednesday January 18, 2023.

1. CS-1

APPROVED

- End of Submittal Comments -

THIS REVIEW PERFORMED BY BERNHARD TME, LLC, IS ONLY FOR GENERAL CONFORMANCE WITH THE DESIGN CONCEPT OF THE PROJECT AND GENERAL COMPLIANCE WITH THE INFORMATION PROVIDED IN THE CONTRACT DOCUMENTS. CORRECTIONS OR COMMENTS MADE ON THE SUBMITTAL AND/OR SHOP DRAWINGS DURING THIS REVIEW DO NOT RELIEVE THE CONTRACTOR FROM COMPLIANCE WITH THE REQUIREMENTS OF THE PLANS, SPECIFICATIONS, AND OTHER CONTRACT DOCUMENTS. APPROVAL OF A SPECIFIC ITEM SHALL NOT INDICATE AN APPROVAL OF AN ASSEMBLY OF WHICH THE ITEM IS A COMPONENT. CONTRACTOR IS RESPONSIBLE FOR THE FOLLOWING: ALL QUANTITIES; CONFIGURATION OF COMPONENTS; DIMENSIONS TO BE CONFIRMED AND CORRELATED AT THE JOBSITE; INFORMATION THAT PERTAINS SOLELY TO THE FABRICATION PROCESS OR TO THE MEANS, METHODS, TECHNIQUES, SEQUENCES, AND PROCEDURES OF CONSTRUCTION; COORDINATION OF THE WORK WITH THAT OF ALL OTHER TRADES; AND, FOR PERFORMING ALL WORK IN A SAFE AND SATISFACTORY MANNER.



SUBMITTAL SHEET

Alessi Keyes Construction Co. AKC-505 - Booneville HDC New Dorm

Project: AKC-505 Booneville HDC New Dorm

,

Spec Section Num:22 43 00Submittal:22.17Revision:0Package:PlumbingDate:1/19/2023 UTC

Submittal Title:Healthcare Plumbing FixturesSubmittal Detail:2/15/2023 UTC

Contractor:

Charley Dawson Alessi-Keyes Construction Co. Contractor's Stamp

Architect: Trey Tassin Stocks-Mann Architects Architect's Stamp

Response: Comment: CS-1 CLINICAL SINK AM. STANDARD 9504.000 FLUSHING RIM SINK ZURN Z6017-0-H-YK-YBYC WITH OFFSET TAILPIECE T&S B-0664-03 FAUCET 7852504.075 RIM GUARD WILLIAMS 1028 TERRAZZO BASE

American tandard

Clinic Service Sink Floor Mount

9504.999.020

- Vitreous china
- Floor mount
- · Flushing rim
- Siphon jet flushing action
- 1-1/2" top spud
- · White Only
- Includes bolt caps

FLUSH VOLUME: 6.5 gpf / 24.6 Lpf

OPERATING PRESSURE: 25 psi (flowing) - 80 psi (static)

FLOW REQUIREMENT: 25 gpm (96.6 L/min.)

Available Components:

710098-201.081 Pedestal base, black on white finish

7832504.075 Rim guard, service sink, floor

Nominal Dimensions:

743 x 508 x 457mm (29-1/4" x 20" x 18")

NOTES:

- Fixture conforms to ANSI/ASME A112.19.2M standards
- Optional one, two or three rim guards available when specified and ordered accordingly (not shown)
- Optional pedestal base (approximately 28"x14"x10") available when specified and ordered accordingly (as shown)
- Flush valve specifications: Flush valve with 1" angle stop, 1-1/2" vacuum breaker and flush connection.

FLUSH VALVE RECOMMENDATION:

American Standard 6047117.002 or equivalent

OPTIONAL ACCESSORIES


- Bedpan Diverter: American Standard 6047800.002 / 6047815.002 or equivalent
- Service Sink Faucet: American Standard 8345.115 or equivalent


NOTES:

- CUSTOMER SHOULD CHECK WITH GENERAL CONTRACTOR TO DETERMINE IF BASE IS BEING PROVIDED BEFORE PROCEEDING WITH
- ROUGHING-IN MEASUREMENTS. • VARIABLE-CHECK WITH MANUFACTURER OF FLUSHVALVE FOR PROPER ROUGHING-IN DIMENSIONS.
- *** VARIABLE-CHECK WITH MANUFACTURER OF SERVICE SINK FAUCET FOR PROPER ROUGHING-IN DIMENSIONS.

IMPORTANT: Roughing-in dimensions may vary 1/2" and are subject to change or cancellation without prior notice. No responsibility is assumed for use of superseded or voided leaflets.

Available in White Only






Clinic Service Sink Floor Mount VITREOUS CHINA



Exposed Z6017-O2.0 Model for Service Sinks with 2" Offset



Flow Options

-Standard Flush 6.5 Gallons Per Flush

Suffix Options (Check/Specify Appropriate Options)


outine option	o (olloola obcou) tibbi obligate obligi
् 🗆 -BG	BioCare ADA Handle
H	Handle on Front of Flush Valve
- L	1" [25] Metal Push Button
🗆 -L3	3" [76] Metal Push Button
、□ -VC	Vandal Resistant Stop Cover
YB	Sweat Solder Kit
C	Cast Wall Flange
⊂-YH	One Wall Bumper
、□-YJ	Split Ring Pipe Support
STAND -YK	Solid Ring Pipe Support
	Other
 	

ENGINEERING SPECIFICATION: ZURN Z6017O2.0 Aquaflush Exposed Clinic Service Sink Flush Valve -Exposed, quiet diaphragm-type, chrome plated flushometer valve with a polished exterior. Complete with a chloramine resistant, dual seal diaphragm with a clog resistant by-pass. The valve is ADA compliant with a non-hold-open and no leak handle feature, high back pressure vacuum breaker, one piece hex coupling nut, adjustable tailpiece, spud coupling and flange for top spud connection. Control stop has internal siphonguard protection. Internal seals are made of chloramine resistant materials.

-Z6017PL-O2.0- Aquaflush Plus is furnished as specified above and includes sweat solder kit, vandal resistant stop cap, and cast wall flange.

Architectural/Engineering

ZURN INDUSTRIES, LLC. ♦ COMMERCIAL BRASS OPERATION ♦ 5900 ELWIN BUCHANAN DRIVE ♦ SANFORD NC 27330 PHONE: 1-800-997-3876 ♦ FAX: 919-775-3541 ♦ WORLD WIDE WEB: WWW.ZURN.COM IN CANADA: ZURN INDUSTRIES LIMITED ♦ 3544 NASHUA DRIVE ♦ MISSISSAUGA, ONTARIO L4V1L2 ♦ PHONE: 905-405-8272 FAX: 905-405-1292






T&S BRASS AND BRONZE WORKS, INC.

2 Saddleback Cove / P.O. Box 1088 Travelers Rest, SC 29690

Model No.

B-0664-03



Drawn:	MRC	Checked:	JRM	Approved:	JHB	Date:	11/02/18	Scale:	NTS	Sheet: 2 of 2

ANSI A117.1 (ADA) ASSE 1001 (VB)

Female Inlets, Intergral Service Stops & Garden Hose Male Outlet

