


1 PLUMBING PLAN - OVERALL - HENDERSON - BUILDING 600 1/8" = 1'-0"

KEYED NOTES

- 1 CONNECT NEW V LINE TO EXISTING PLUMBING PIPING IN TOILET ROOM AT APPROXIMATELY THIS LOCATION.
- 2 CONNECT NEW 1/2" CW/HW PIPING TO EXISTING CW/HW PIPING IN MEP ROOM AT APPROXIMATELY THIS LOCATION.
- 3 3/4" CA DOWN TO HOSE REEL MOUNTED ON WALL OR SUSPENDED FROM STRUCTURE ~6'6" AFF. COORDINATE FINAL LOCATION WITH OWNER, REFERENCE DETAIL FOR MORE INFORMATION.
- 4 AUTOMATIC COMPRESSED AIR DRAIN. ATLAS EWD-330. INSTALL AT LOW POINT OF PIPING. ROUTE DRAIN LINE TO EXTERIOR. 5 COMPRESSED AIR CONDENSATE DRAIN
- ROUTED TO EXTERIOR. 6 CONNECT NEW SS LINE TO EXISTING BUILDING DRAIN LINE ON THE EXTERIOR OF THE BUILDING AT APPROXIMATELY THIS LOCATION. ROUTE PLUMBING PIPING AS NEEDED AND ENSURE NEW SS LINE HAS MINIMUM 1/8" / 12"
- SLOPE. $\sqrt{}$ 2 7 COMPRESSED AIR DROP TO OWNER PROVIDED EQUIPMENT, TERMINATE WITH BALL VALVE. COORDINATE WITH OWNER FOR FINAL LOCATION AND MANUFACTURER'S CUT SHEET FOR REQUIRED IN-LINE ACCESSORIES.



WILLIAM THOMAS MOORE, AIA ARCHITECT 1300 East 6th Street Little Rock, Arkansas 72202 501-372-2900